Making and booting flash for Android through PC

Directed by MZ Minhaz

A. Install driver in manually through ""Device Manager""

~~~~Action (Manu bar) >> Add legacy hardware (Manu)~~~~

Note: If problem then deactivate "signature" process.

## way to deactivate:

- 1. Hold "Shift" + Restart PC.
- 2. Go to --> Troubleshoot --> Advanced Options --> Startup Settings
- 3. Then hit the restart button and select the signature e/d entry button.
- 4. It will enable the non-signature installation for that only reboot.
- 5. & goes to default after next reboot automatically...... Done

## B. Making Flash:

- 1. Click on ""Load packet"" and load (.pac) file (FactoryDownload R2.9.9015)
- 2. Click on ""Start Downloading""
- 3. plug in cable with PC & Power off phone.
- 4. Hold ""Down Volume"" button of phone and plug in phone with PC.
- 5. Holding the button till the downloading pop up bar doesn't show in.
- 6. Release the button and wait till the process shows finished.
- 7. Press the "Stop Downloading" button and exit phone from pc.... Done

Note: Don't unplugged phone in the process mode, or it can software crushed.